



XR-8M and XR-12M

Alphanumeric Remote Displays



Installation Instructions

© Avery Weigh-Tronix, LLC 2011. All rights reserved.

No part of this publication may be reproduced, stored in an electronic retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written consent of the copyright owner, or as permitted by law or under license. Full acknowledgment of the source must be given. Avery Weigh-Tronix is a registered trade mark of the Avery Weigh-Tronix, LLC. This publication was correct at the time of going to print however, Avery Weigh-Tronix, LLC reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

All third party brands and product names used within this document are trademarks or registered trademarks of their respective holders.

Table of Contents

	<i>page</i>
Chapter 1 General information and warnings	7
About this manual	7
Text conventions	7
Special messages	7
Installation	8
Electrical installation	8
Pluggable equipment	8
Permanently wired equipment - Isolator requirements	8
Safe handling of equipment with batteries	9
Wet conditions	9
Routine maintenance	9
Cleaning the machine	9
Training	9
Sharp objects	10
FCC and EMC declarations of compliance	10
Chapter 2 Introduction	11
Displays	12
Keypad	13
Opening the XR Enclosure	13
Lowering the Electronics Plate	14
Circuit Boards	15
Chapter 3 Installation	16
Receiving Inspection	16
Mounting Instructions	16
Communications Wiring	17
Chapter 4 START-UP	20
Power ON/OFF	20
Reset Button	20
Auto-Learn	20
Learn Button	21
Diagnostic Indicator Lights	21
Bargraph Function	22
Chapter 5 Configuration Mode	23
Entering Configuration Mode	23
Navigating Configuration Parameters	23
Editing Configuration Parameters	23
Exit & Save Configuration	24
Configuration Parameters	24
Parameter 1.0: Daytime Brightness Level	24
Parameter 1.1: Nighttime Brightness Level	24
Parameter 1.2: Power-Save Mode	25
Parameter 1.3: Mirror Display Mode	25
Parameter 1.4: Multi-Drop ID	25
Parameter 1.5: Radio Channel Select	26
Parameter 1.6: Utility Program Select	26
Auto-learn Parameters	26
Parameter 2.0: Manual Learn (Assisted Learn)	26
Parameter 2.1: Start-up Auto-Learn	27

Parameter 2.2: Leading Zero Suppression	27
Parameter 2.3: Set Scale Over	27
Parameter 2.4: Lock Units	28
Parameter 2.5: Lock Weighing Mode	28
Time / Date / Temp Parameters	28
Parameter 3.0: Time Display	28
Parameter 3.1: Date Display	29
Parameter 3.2: Temperature Display	29
Parameter 3.3: Weight Display	29
Parameter 3.4: Time Threshold	29
Dlagnostic Parameters	30
Parameter 9.0: Com Port	30
Parameter 9.1: String Counter	30
Parameter 9.2: Baud Rate	30
Parameter 9.3: Configuration Lockout	30
Parameter 9.4: Number Counter	31
Parameter 9.8: Test Display	31
Parameter 9.9: Reset Defaults	31
Chapter 6 Utility Programs	32
Program 0: Normal Operation	32
Program 4: Freeze Weight (Capture Print String)	32
Program 5: Command Mode (G2)	32
Activating Command Mode	32
Transmit a Weight String	32
Transmit Status Characters	33
Transmit an Alphanumeric Message / Data String	33
Control Commands	33
Sample Command Mode Data Strings	34
Multi-Drop IDs & Networking	36
Chapter 7 Time & Date	37
Set Time & Date	37
Adjust Time	37
Adjust Date	37
Battery Replacement	38
Chapter 8 Wireless Setup	39
XR Integrated Wireless Installation	39
Indicator & Wireless Transceiver	41
Wireless Connection Test	41
Chapter 9 Temperature Probe Installation	42
Chapter 10 Troubleshooting & Error Messages	44
Chapter 11 Parts	46

Manual revision history

Current Issue	Date Created	Details of Changes
AA	May 2010	New manual
AB	August 2010	minor changes
AC	November 2010	Added parts list and info on bargraphs
AD	January 2011	Corrected photo in Figure 8.1 and added Parameter 1.6 to Chapter 5.

1 General information and warnings

1.1 About this manual

This manual is divided into chapters by the chapter number and the large text at the top of a page. Subsections are labeled as shown by the 1 and 1.1 headings shown above. The names of the chapter and the next subsection level appear at the top of alternating pages of the manual to remind you of where you are in the manual. The manual name and page numbers appear at the bottom of the pages.

1.1.1 Text conventions

Key names are shown in **bold** and reflect the case of the key being described. This applies to hard keys and onscreen or soft keys.

Displayed messages appear in ***bold italic*** type and reflect the case of the displayed message.

1.1.2 Special messages

Examples of special messages you will see in this manual are defined below. The signal words have specific meanings to alert you to additional information or the relative level of hazard.



ELECTRICAL WARNING!
THIS IS AN ELECTRICAL WARNING SYMBOL.
ELECTRICAL WARNINGS MEAN THAT FAILURE TO FOLLOW SPECIFIC PRACTICES OR PROCEDURES MAY RESULT IN ELECTROCUTION, ARC BURNS, EXPLOSIONS OR OTHER HAZARDS THAT MAY CAUSE INJURY OR DEATH.



WARNING!
This is a Warning symbol.
Warnings mean that failure to follow specific practices and procedures may have major consequences such as injury or death.



CAUTION!
This is a Caution symbol.
Cautions give information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.



NOTE: This is a Note symbol. Notes give additional and important information, hints and tips that help you to use your product.

1.2 Installation



DANGER: RISK OF ELECTRICAL SHOCK. NO USER SERVICEABLE PARTS. REFER TO QUALIFIED SERVICE PERSONNEL FOR SERVICE.

1.3 Electrical installation



CAUTION: The power cable must be connected to an earth-grounded electrical outlet. The electrical supply must have a circuit breaker with an appropriate rating to protect from over-current conditions.

For your protection, all electrical (110V or 230V) equipment used out of doors or in wet or damp conditions should be supplied from a correctly fused power source and protected by an approved ground fault protection device (RCD, GFCI etc.)

IF IN DOUBT SEEK ADVICE FROM A QUALIFIED ELECTRICIAN.

1.3.1 Pluggable equipment

Pluggable equipment must be installed near an easily accessible socket outlet.

1.3.2 Permanently wired equipment - Isolator requirements

Permanently connected equipment must have a readily accessible disconnect device incorporated in the fixed wiring such as an isolator or circuit breaker with at least 3mm contact separation.

The isolator **MUST NOT** be installed into the flexible power cable supplied with the unit.

1.3.3 Safe handling of equipment with batteries



CAUTION: *Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.*

ATTENTION: *Il y a danger d'explosion s'il y a remplacement incorrect de la batterie, remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.*

1.3.4 Wet conditions

Under wet conditions, the plug must be connected to the final branch circuit via an appropriate socket / receptacle designed for washdown use.

Installations within the USA should use a cover that meets NEMA 3R specifications as required by the National Electrical Code under section 410-57. This allows the unit to be plugged in with a rain tight cover fitted over the plug.

1.4 Routine maintenance

Always turn off the machine and isolate from the power supply before starting any routine maintenance to avoid the possibility of electric shock.

Make sure that it is placed securely on a flat and level surface.

1.5 Cleaning the machine

Table 1.1 Cleaning DOs and DON'Ts



DO	DO NOT
Wipe down the outside of standard products with a clean cloth, moistened with water and a small amount of mild detergent	Attempt to clean the inside of the machine
	Use harsh abrasives, solvents, scouring cleaners or alkaline cleaning solutions
Spray the cloth when using a proprietary cleaning fluid	Spray any liquid directly on to the display windows

1.6 Training

Do not attempt to operate or complete any procedure on a machine unless you have received the appropriate training or read the instruction books.

1.7 Sharp objects

Do not use sharp objects such as screwdrivers or long fingernails to operate the keys.

1.8 FCC and EMC declarations of compliance

United States

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Canada

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Classe A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

European Countries

WARNING: This is a Class A product. In a domestic environment, this product may cause radio interference in which the user may be required to take adequate measures.

2 Introduction

The XR-8M and XR-12M remote displays incorporate the most features and highest performance standards of any weighing display, making them the best choice for remote viewing applications. The series has complete alphanumeric messaging capabilities, an external keypad and standard time and date. Like all Avery Weigh-Tronix products, the remote displays are designed with durability, functionality, and versatility in mind.

If you should need technical assistance, please contact your local, authorized Avery Weigh-Tronix distributor.



ATTENTION! Unauthorized installation and service of this unit may void the warranty.

2.1 Displays

Figure 2.1 shows the displays of the two models; XR-8M and XR-12M.




Figure 2.1 XR-8M and XR-12M displays

Model	# of Characters	Character Height	Character Matrix
XR-8M	8	4.0 inches	5 x 7
XR-12M	12	3.5 inches	5 x 7

The following annunciators appear on the display of each model:

- *GR* = Gross weighing mode
- *NT* = Net weighing mode
- *lb* = Pounds
- *kg* = Kilograms

2.2 Keypad

The membrane keypad features an integrated light sensor window to detect changing ambient light conditions and 3 tactile push buttons used to set time and date (see *Set Time & Date on page 37*) as well as access configuration mode (see *Entering Configuration Mode on page 23*).




Figure 2.2 Keypad

2.3 Opening the XR Enclosure

1. Make sure the unit is disconnected from power.
2. Remove the Phillips head screws from each side of the enclosure.
3. Slowly, guide the front cover off of the main enclosure. See Figure 2.3..




Figure 2.3 Side view of opening the enclosure

2.4 Lowering the Electronics Plate

1. Remove the three (3) captive screws holding the electronics plate to the main enclosure. See Figure 2.4.




Figure 2.4 Open enclosure

2. Slowly, allow the electronics plate to swing down. The controller board and power supply board are now accessible for installation, wiring and service. See Figure 2.5.




Figure 2.5 Electronics plate down

2.4.1 Circuit Boards




Figure 2.6 Display Boards




Figure 2.7 Controller and power boards

3 Installation

3.1 Receiving Inspection

It is always good practice to verify that the XR display is complete and undamaged upon receipt.

- Check over packaging for any signs of damage.
- Remove the XR display from its protective packaging and check for damage.
- Verify that the shipment includes:
 - XR display (complete and intact)
 - XR Installation Manual

3.2 Mounting Instructions

Dimensions and mounting-hole patterns for the XR display (XR-8M & XR-12M) are given in Figure 3.1.




Figure 3.1 Dimensions and hole pattern

1. Inspect the installation site for properly grounded power. The socket-outlet shall be installed near the equipment and shall be easily accessible.
2. Ensure that mounting structures will bear the weight of the display (XR-8M & 12: 26.5 lb / 12 kg).
3. Allow proper clearance for lifting and removing the front cover.
4. Use proper hardware, including wall anchors, where necessary, when mounting the enclosure. The hex cap bolt length is specified as minimum. The appropriate length must be determined specifically for each application.

Imperial:

5/16-18 UNC Hex Cap Bolts - 4pcs/unit (min. 1" long)

5/16 Steel Flat Washer - 4pcs/unit

Metric:

M8x1.25 Hex Cap Bolts - 4pcs/unit (min. 25mm long)

M8 Steel Flat Washer - 4pcs/unit

- Run communication cables up into the enclosure via strain reliefs as necessary. See Figure 3.2.




Figure 3.2 Strain reliefs

3.3 Communications Wiring

All communications wiring terminates at the controller board. See Figure 3.3. Communications should be wired before applying power to the unit.





Figure 3.3 Communication terminals

RS-232 Wiring

Terminate the indicator's communication wires at the RS-232 terminal (J3). See Fig. 3.3 and the table below:


INDICATOR	XR REMOTE DISPLAY
TRANSMIT (TX)	RECEIVE (RCX)
SIGNAL GROUND (GND)	SIGNAL GROUND (GND)

RS-232 Daisy Chain / Multi-Drop Wiring




RS-485 / 422 Wiring

Terminate the indicator's communication wires at the RS-485 terminal (J4). See Fig. 3.3 & table below:




RS-485 Daisy Chain / Multi-Drop Wiring

Parallel Wiring



Split Wiring




20 mA Current Loop Wiring

Terminate the indicator's communication wires at the 20 mA Current Loop terminal (J5). See Fig. 3.3 & table below:



20 mA Current Loop Mode Switch



After the current loop is wired, ACTIVE or PASSIVE mode must be selected via the switch on the controller board (SW 10). See illustration at left.

Select ACTIVE if the XR is required to supply the 20 mA current to the communicating device (indicator).

Select PASSIVE if the communicating device (indicator) supplies the current to the XR display. If unsure of these requirements, check the device's manual.

4 START-UP

4.1 Power ON/OFF

The XR has no ON/OFF button or switch. Plugging the unit into AC power will turn the unit ON. Disconnecting AC power will turn the unit OFF.

Once power is applied, the XR performs a self test by counting up 1 to 9, flashing annunciators and decimals, and displaying the software revision number (Ex. 4-00).

4.2 Reset Button

The **RESET** button on the controller board allows technicians to cycle power on the unit without disconnecting/connecting AC power. See Figure 4.1




Figure 4.1 RESET button on controller board

4.3 Auto-Learn

On power up, the XR automatically enters Auto-Learn Mode, analyzing the serial communications settings and incoming data from the indicator.

The output string must contain number characters. An STX character (ASCII 02) and/or CR character (ASCII 13) must also be included.

Auto-Learn Examples:

123456<SP><UM><CR>

<STX>123456<CR>

nk 12345 <CR>

The data string for Auto-Learn must terminate with a <CR>

Once Auto-Learn is successful (about 10 seconds after power up) the current weight is displayed.



Automatic Start-up Auto-Learn may be disabled for custom applications. Please see Auto-learn Parameters [on page 26](#).

4.4 Learn Button

If Automatic Start-up Auto-Learn is disabled, the **LEARN** button on the controller board, see Figure 4.2, must be pressed to enter Auto-Learn Mode.




Figure 4.2 LEARN button

4.5 Diagnostic Indicator Lights

The XR has 7 diagnostic indicator lights located on the controller board. Each is pointed out in Figure 4.3.

- | | |
|----------------------|--|
| 3.3V Light: | Turns ON when voltage is supplied to the controller board. |
| 12V Light: | Turns ON when voltage is supplied to the Display boards. |
| STATUS Light: | The XR's "heartbeat". BLINKS when the processor is running.

Rapid blinking (3 times per second) indicates that the XR is in Auto-Learn Mode, attempting to interpret a data string.

Regular blinking (Once per second) indicates that the XR has successfully learned a data string and is running properly. |
| RS232 Light: | FLASHES ON each time the XR receives a character through the RS232 com port. |
| RS485 Light: | FLASHES ON each time the XR receives a character through the RS485 com port. |
| 20mA Light: | FLASHES ON each time the XR receives a character through the 20 mA Current Loop port. |
| RADIO Light: | FLASHES ON when the XR's Radio Module receives data.

This light will only illuminate if the Radio Module is installed. |




Figure 4.3 Controller board diagnostic lights

4.6 Bargraph Function

There is a bargraph feature in the XR remote displays. This allows you to graphically represent the weight as a bargraph on the display.

To setup the bargraph see *Control Commands* on page 33 and *Sample Command Mode Data Strings* on page 34.



To disable bargraph, set both MIN and MAX weights to “0” in *Control Commands* on page 33.

Set the minimum and maximum weights you want displayed and as the weight increases or decreases, the bargraph will move across the display. Halfway between the MIN and MAX weight the bargraph will be at 50% (independent of scale units).

5 Configuration Mode

5.1 Entering Configuration Mode

1. Press & hold the **UP** and **DOWN ARROW** keys together.
2. **ConFig** is flashed on the display.
3. The first configuration mode parameter (P1.0) is displayed.




In configuration mode, if no keys are pressed for 10 seconds, the scale weight is displayed with a blinking "C" on the left-hand side.

5.2 Navigating Configuration Parameters

Use the **UP** and **DOWN ARROW** keys to find the parameter. Configuration parameters are displayed by the letter **P** preceding the parameter number (Ex. **P1.0**, **P1.1**, **P1.2** ...”).




*Hold down the **UP** or **DOWN ARROW** key for more than 1 second to scroll through the configuration sub-blocks for quicker navigation (Ex. P1.0, P2.0, P3.0 ...”).*



5.3 Editing Configuration Parameters

1. Navigate to the parameter and press **ENTER** to display the parameter value.
2. Use the **UP** and **DOWN ARROW** keys to edit the parameter value.
3. Press **ENTER** to confirm the parameter value.



5.4 Exit & Save Configuration

1. Press the **UP** and **DOWN ARROW** keys together.
2. The display flashes **SAvE** and **rESEt** before exiting configuration mode. All configuration information is saved and the display resets itself for normal operation.

5.5 Configuration Parameters

5.5.1 Parameter 1.0: Daytime Brightness Level



Factory default settings are indicated by a left arrow (<) in the tables below.

Value	Description
0 = Low	Set the brightness of the display for daytime viewing. The built-in light sensor automatically detects daylight conditions and sets the display brightness to this level.
1 = Med Low	
2 = Med High	
3 = High <	

5.5.2 Parameter 1.1: Nighttime Brightness Level

Value	Description
0 = Low <	Set the brightness of the display for nighttime viewing. The built-in light sensor automatically detects night conditions and sets the display brightness to this level.
1 = Med Low	
2 = Med High	
3 = High	



Lowering the brightness level at night helps reduce nighttime glare and energy costs. Passing headlights, spotlights, etc. will NOT activate the daytime brightness level.

5.5.3 Parameter 1.2: Power-Save Mode

Value	Description
0 = OFF 1 = ON <	Automatically dims display brightness one level below the selected brightness level (day or night, as applicable) if there is no activity on the scale for 10 minutes. Brightness levels are restored when motion is detected on the scale. This feature saves power and increases LED longevity.

5.5.4 Parameter 1.3: Mirror Display Mode

Value	Description
0 = OFF < 1 = Mirror 2 = Cycle	Mirror display for viewing from a vehicle's rear-view or side-view mirrors. When "Cycle" is selected, the display will cycle between Normal and Mirror Display Modes every 5 seconds.

5.5.5 Parameter 1.4: Multi-Drop ID

Value	Description
0= ID 0 < 1= ID 1 2= ID 2 3= ID 3 Etc.	Sets the unit ID if multiple remote displays are networked together. Up to four (4) XR displays can be networked on a single serial or radio connection. Messages are sent to individual displays using control codes and these IDs. For Multi-Drop instructions, see <i>Multi-Drop IDs & Networking on page 36</i> .



If Multi-Drop is not being used, it is very important that the Multi-Drop ID be set to 0.

5.5.6 Parameter 1.5: Radio Channel Select

Value	Description
0 = Ch 0 <	Sets the radio frequency channel (0-5) for the optional Integrated Wireless Module. If there are multiple scale/remote display installations at a given site, each installation must have its own unique radio channel selected to prevent interference.
1 = Ch 1	
2 = Ch 2	
3 = Ch 3	
4 = Ch 4	
5 = Ch 5	



The XR remote display must be set to the same radio channel as the scale indicator's wireless transceiver.

If the wireless connection experiences interference problems from another radio site, switching radio channels will most likely correct the problem.

5.5.7 Parameter 1.6: Utility Program Select

Value	Description
0 = OFF<	Several Utility Programs are pre-installed in the XR remote display. For a complete list of programs and descriptions, see <i>Utility Programs</i> on page 32.
1 = Pgm 1 - Green light at 0	
2 = Pgm 2 - Red light on motion	
3 = Pgm 3 - Normal w/ Cmds	
4 = Pgm 4 - Freeze weight	
5 = Pgm 5 - Command mode-G2 Etc.	

5.6 Auto-learn Parameters

5.6.1 Parameter 2.0: Manual Learn (Assisted Learn)

Value	Description
Lxxxxx	<p>Manual Learn activates Auto-Learn Mode from inside configuration mode. The remote display will analyze and attempt to learn the string. The message "LEARN" will be displayed. When the remote display is successful, the weight will be shown on the display.</p> <p>A blinking L will be displayed in the left hand corner to indicate you are still in learning mode.</p> <p>To lock in the learned string's settings, press ENTER.</p>

5.6.2 Parameter 2.1: Start-up Auto-Learn

Value	Description
0 = OFF 1 = ON <	The XR automatically enters Auto-Learn Mode on start up. If OFF, the display will startup using settings stored in memory from the last learn. Parameter 2.0 must be activated or the LEARN button on the controller board must be pressed before the XR will go into Auto-Learn Mode again.

5.6.3 Parameter 2.2: Leading Zero Suppression

Value	Description
0 = OFF < 1 = ON	In some cases, the scale indicator may transmit leading zeros in the output string. If leading zeros are NOT required, they may be suppressed. The XR will automatically remove the leading zeros and replace them with blank spaces on the display.



Leading Zeros may also be disabled using the scale indicator (if possible).

5.6.4 Parameter 2.3: Set Scale Over

Value	Description
0 = Auto < Value for scale over target weight.	If there is no scale over status character in the weight string, or the indicator continues to transmit past maximum capacity, the unit can be set to blank the display when the weight goes past a preset weight value. Use the UP/DOWN keys to set the weight threshold and press ENTER . Holding the keys down will cause the weight threshold to change in steps of 10000. Single key presses will cause the weight threshold to change in steps of 100.

5.6.5 Parameter 2.4: Lock Units

Value	Description
0 = Auto < 1 = lb ON (or t) 2 = kg ON 3 = Both OFF	Weight Units (lb, kg, and t) are automatically displayed from the indicator's output string. The Units annunciators may be locked on or off as required. On European models the lb enunciator is replaced with t.

5.6.6 Parameter 2.5: Lock Weighing Mode

Value	Description
0 = Auto < 1 = Gross ON 2 = Net ON 3 = Both OFF	Weighing Mode (Gross/Net) is automatically displayed from the indicator's output string. The Mode annunciators may be locked on or off as required.

5.7 Time / Date / Temp Parameters

XR displays can cycle between displaying weight, time and date every 5 seconds when: a) the weight display is at zero AND; b) there is no activity on the scale for the selected time period.

5.7.1 Parameter 3.0: Time Display

Value	Description
0 = OFF < 1 = Time (AM/ PM) 2 = Military (24 Hour)	Activates the TIME function in 12 hour or 24 hour clock formats.

5.7.2 Parameter 3.1: Date Display

Value	Description
0 = OFF < 1= MMDDYY (US Format) 2 = YYMMDD (International) 3 = DDMMYY (UK)	Activates the DATE function in US, ISO or UK format.

5.7.3 Parameter 3.2: Temperature Display

Value	Description
0 = OFF < 1 = °F (degrees Fahrenheit) 2 = °C (degrees Celsius)	Activates the temperature function (in °F or °C) when the optional temperature probe is installed.

5.7.4 Parameter 3.3: Weight Display

Value	Description
0 = OFF 1 = Cycle 2 = No Cycle <	OFF: Weight will NOT BE DISPLAYED at all. ON: Weight is displayed in the "Time/Date/Temp/Weight Cycle". No Cycle: Weight is NOT in the "Time/Date/Temp/Weight Cycle".

5.7.5 Parameter 3.4: Time Threshold

Value	Description
1 to 20 min. 1 min <	Selects the number of minutes that the scale must be at zero before the "Time/Date/Temp/Weight Cycle" is displayed.

5.8 Diagnostic Parameters

5.8.1 Parameter 9.0: Com Port

Value	Description
0 = RS232 1 = RADIO 2 = 20mA 3 = RS485	Displays the currently active Com Port.

5.8.2 Parameter 9.1: String Counter

Value	Description
0 to 65535	Counter indicates the number of characters received. Counter rolls over after 65535.

5.8.3 Parameter 9.2: Baud Rate

Value	Description
300 600 1200 4800 9600 19200	Displays the baud rate currently being utilized for serial communications.

5.8.4 Parameter 9.3: Configuration Lockout

Value	Description
0 = Disabled < 1 = Enabled	When enabled, no configuration parameters can be changed. Disable this parameter to allow changes.

5.8.5 Parameter 9.4: Number Counter

Value	Description
0 to 65535	Counter indicates the number of numeric characters received. Counter rolls over after 65535.

5.8.6 Parameter 9.8: Test Display

Value	Description
N/A	Cycles through time, digits, annunciators & decimal characters (as applicable).

5.8.7 Parameter 9.9: Reset Defaults

Value	Description
0 = Do Not Reset 1 = RESET	Resets Configuration Parameters to factory defaults.

6 Utility Programs

The XR displays have several auxiliary functions that may be activated via Parameter 1.6 in configuration mode.

6.1 Program 0: Normal Operation

- No Utility Program is selected.

6.2 Program 4: Freeze Weight (Capture Print String)

- This program is useful in applications where a weight value must be displayed regardless of what is happening on the scale.
- A weigh ticket (using ASCII characters) must be created on the scale indicator that sends the scale weight and a <CR> character to the XR display with a button press.

Example: 123456 lb g<CR>

- When the XR receives the ticket, it displays the weight and keeps displaying it until the next weigh ticket is received.



This application assumes a legal-for-trade indicator is used to send the weigh ticket. Please review local Weights and Measures requirements.

6.3 Program 5: Command Mode (G2)

All XR displays can be setup to receive commands directly from the scale system or PC. Supported commands include transmitting weights, basic alphanumeric messaging, and additional display functions.

Command Mode disables Auto-Learn and fixes communications at 9600-N-8-1. The XR looks only for specific commands sent by the indicator or scale controller.

6.3.1 Activating Command Mode

To enable Command Mode for the XR-8M and XR-12M, set Parameter 1.6 in configuration mode to 5.

6.3.2 Transmit a Weight String

Use numeric ASCII characters followed by a <CR> character. Weights are displayed from right to left.

Example:

- To display **1000**, transmit: 1000<CR>

6.3.3 Transmit Status Characters

Status characters may be embedded anywhere in the weight string to control the annunciator lights. Status characters may be upper or lowercase, and in any order, before or after the weight.

STATUS COMMAND	ASCII	DECIMAL
GROSS weight	G or g	71 or 103
NET weight	N or n	78 or 110
POUNDS	L or l	76 or 108
KILOGRAMS	K or k	75 or 107

Example: To display 1000 lb gross, transmit: **1000LG<CR>** OR **g11000<CR>**



If no gross/net character is sent, the “GR” annunciator will illuminate by default.

6.3.4 Transmit an Alphanumeric Message / Data String

When in Command Mode, XR models can display the entire printable ASCII character set and scrolling messages. When an alphanumeric data string is longer than the unit's number of display characters, the message will scroll (right to left). The maximum data string length is 40 characters.

Alphanumeric message data strings must be preceded by the “ character (decimal 34) and followed by a Carriage Return <CR> character (decimal 13) to differentiate them from weight strings. Characters are displayed from left to right.

6.3.5 Control Commands

Control commands are ASCII characters (preceded by @ and followed by <CR>) that are transmitted to the XR to control additional features.

CONTROL COMMAND	ASCII	DECIMAL
Turn ON flashing display	(40
Turn OFF flashing display)	41
FLASH display 3 times	!	33
Scroll speed (0, fastest to 9, slowest)	=	61
MINIMUM weight for bargraph	>	62
MAXIMUM weight for bargraph	<	60

6.3.6 Sample Command Mode Data Strings

DATA STRING	DISPLAY
0<CR>	"0" gross
1000 <CR>	"1000" gross
LN 1234 <CR>	"1234" lb net
1234 L g <CR>	"1234" lb gross
"hello<CR>	"hELLO"
"XR-8M<CR>@!<CR>	"XR-8M" flashing 3 times
"Avery Weigh-Tronix<CR>	"Avery Weigh-Tronix" scrolling
"Avery Weigh-Tronix!<CR>	"Avery Weigh-Tronix!" scrolling
@=9<CR>"Avery Weigh-Tronix<CR>	"Avery Weigh-Tronix" slow scroll
123456<SP><UM><CR>	6 digits of weight with leading spaces, Unit of measure.
@>0<CR>@<5000<CR>	*Bargraph will display from 0 to 5000. Example: At 2500, the bargraph will be at 50% (independent of scale units).

* To disable bargraph, set both MIN and MAX weights to "0".

Displayable Alphanumeric Character Set:

Control Character	ASCII Code #	Control Character	ASCII Code #	Control Character	ASCII Code #
!	33	A	65	`	96
"	34	B	66	a	97
\$	36	C	67	b	98
%	37	D	68	c	99
&	38	E	69	d	100
'	39	F	70	e	101
(40	G	71	f	102
)	41	H	72	g	103
*	42	I	73	h	104
+	43	J	74	i	105
,	44	K	75	j	106
-	45	L	76	k	107
.	46	M	77	l	108
/	47	N	78	m	109
0	48	O	79	n	110
1	49	P	80	o	111
2	50	Q	81	p	112
3	51	R	82	q	113
4	52	S	83	r	114
5	53	T	84	s	115
6	54	U	85	t	116
7	55	V	86	u	117
8	56	W	87	v	118
9	57	X	88	w	119
:	58	Y	89	x	120
;	59	Z	90	y	121
<	60	[91	z	122
=	61	\	92		
>	62]	93		
?	63	^	94		
@	64	_	95		

6.3.7 Multi-Drop IDs & Networking

XR displays using Multi-Drop networking must be in command mode. The Multi-drop ID (0 to 3) must also be set (see *Parameter 1.4: Multi-Drop ID* on page 25).

When using Multi-drop, the XR will only respond after it has been selected.

To select a display, transmit a # character (ASCII 35) followed by the correct ID number and a <CR> character (ASCII 13). Once this command is executed, control codes, alphanumeric messages and weight strings can be transmitted to the selected display as described in *Program 5: Command Mode (G2)* on page 32.

An XR will remain selected until it receives a command containing a different ID.

Examples:

1. Select Multi-drop ID 1:

Transmitting “#1<CR>” selects the display with ID #1.

2. Select Multi-drop ID 3 and send a weight of 1000lb gross:

“#3<CR>”

“1000LG<CR>”

The ID number may also be embedded with the weight string:

“#3 1000LG<CR>”

3. Send 3 different weights to 3 different scoreboards:

“#0 2000LG<CR>#1 3000LG<CR>#2 5000LG<CR>”

4. Send the text “hello” to scoreboard ID 3.

“#3”HELLO<CR>”

7 Time & Date

The XR display has a precision time clock that compensates for variable temperature conditions. The battery on the controller board (J22) provides back-up power for this clock.

7.1 Set Time & Date

7.1.1 Adjust Time

1. Make sure Time is enabled in configuration mode (Parameter 3.0)
2. Press and hold the **UP ARROW/TIME** key.
3. Use the **UP** and **DOWN ARROW** keys to select the correct hour and press **ENTER**.
4. Repeat for minutes and AM/PM if enabled (12 hour clock).

7.1.2 Adjust Date

1. Make sure Date is enabled in configuration mode (Parameter 3.1)
2. Press the **DOWN ARROW/DATE** key.
3. Use the **UP** and **DOWN ARROW** keys to select the correct year/month/day (International) or month/day/year (USA) and press **ENTER**.

7.2 Battery Replacement

The XR displays use a 3 Volt lithium battery. Power is drawn from the battery only when the unit is disconnected from AC power. If time and date are lost when the unit is disconnected from AC power, the battery likely needs replacement. See Figure 7.1.




Figure 7.1 Battery on the controller board

1. Remove the old battery from the J22 terminal on the controller board by hand.
2. Observe proper battery polarity before inserting new battery.
3. Ensure the battery is seated correctly in the J22 terminal.



CAUTION! Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to their instructions.



CAUTION! Never use metal objects such as screwdrivers to remove batteries! This may result in personal injury or damage to the unit.

8 Wireless Setup

8.1 XR Integrated Wireless Installation

The Integrated Wireless Kit includes:

- Radio Module
 - External Antenna
 - Internal Antenna Cable
 - FCC/Industry Canada Sticker
1. Ensure the XR display is disconnected from power and open the enclosure.
 2. Place the radio module in the “Radio Module Option” terminals on the controller board.
 3. Connect the internal antenna cable to the threaded SMA terminal on the radio module.
 4. Remove the rubber plug in the bottom of the XR enclosure. See Figure 8.1



Figure 8.1 Rubber plug

5. Remove the nut and lock washer from the threaded SMA terminal on the internal antenna cable. Run the threaded SMA terminal through the hole in the bottom of the XR enclosure. Use the lock washer and nut to secure the SMA terminal.
6. Connect the external antenna to the SMA connector on the bottom of the enclosure.

7. Power up the XR. The XR is ready to receive radio signals.




Figure 8.2 Radio module on controller board




Figure 8.3 Wireless kit installation

8.2 Indicator & Wireless Transceiver

1. Wire the ScaleLink Transceiver to the indicator (or other communicating device).



2. Verify communication settings between the ScaleLink and the indicator (or other communicating device). The ScaleLink's default communication settings are:
 - Baud Rate 9600
 - Data Bits 8
 - Parity None
 - Stop Bits 1
3. Ensure the indicator is set-up to output **continuously**.
4. Power up the Indicator and transceiver together to transmit radio signals.

8.3 Wireless Connection Test

1. Verify that both the Wireless Transceiver and the XR Remote Display are set to the same radio channel.
2. Verify that the Wireless Transceiver is ON and transmitting.
3. Verify that the Radio LED on the XR controller board is **flashing**. See Figure 8.4.




Figure 8.4 RADIO LED on the controller board

4. Add weight to the scale.
5. Verify that the XR is correctly displaying Weight, Measurement Units (kg, lb), and Weighing Mode (GR, NT) as shown on the scale indicator.



If the XR's readings are incorrect, erratic, or very slow, a different radio channel may need to be selected.



XR Radio Module Field Installation kits are available. Please contact the your Avery Weigh-Tronix distributor for more information.

9 Temperature Probe Installation

1. Unpack the optional Temperature Probe Assembly. This assembly consists of the weather-sealed temperature probe contained in a strain relief. A 4 conductor cable runs from the temperature probe to a 4 pin connector.
2. Ensure the XR display is disconnected from power and open the enclosure.
3. Remove the rubber plug from the hole in the bottom of the enclosure.
4. Remove the nut from the strain relief and run the cable up through the hole in the bottom of the enclosure.
5. Run the connector and cable through the nut and use it to fasten the strain relief to the enclosure.
6. Plug the temperature probe connector into the terminal (J9) on the controller board.
7. Power up the XR display. Enter configuration mode and set Parameter 3.2 to 1 for Fahrenheit or 2 for Celsius.
8. Exit configuration mode. The temperature will be displayed once the remote display has been reading zero for the time specified in Parameter 3.4 (Time Threshold).




Figure 9.1 Temperature probe installation




Figure 9.2 Temperature probe cable connects to J9 on the controller board



The XR's Digital Temperature Probe ensures accuracy to within ± 1 degree and will never need to be calibrated.

10 Troubleshooting & Error Messages

Problem	Cause and/or Probable Solution
Unit won't power up:	<ul style="list-style-type: none"> • Verify AC power source (Outlets, breakers, etc.) • Check power cord connections to terminal block and ground posts inside the main enclosure. • Verify internal power wiring from terminal block to the power supply board and power supply board to the controller board. • Check fuse on power supply board and controller board.
Unit has power, but there is no display.	<ul style="list-style-type: none"> • Verify ribbon cable connections from controller board to the 2 display boards. • Check 12V light and fuse on controller board. • If the unit is in COMMAND mode, the display will remain blank until data is received.
Dashes across the display.	<ul style="list-style-type: none"> • Communications have failed. • Verify the correct terminal (RS-232, 422/485, 20 mA) is being used and check wiring. • Verify cable or radio connection to indicator. • Verify indicator serial port function
Display reads <i>Err 1</i> .	<ul style="list-style-type: none"> • Baud Rate Auto-Learn has failed. • Verify the correct terminal (RS-232, 422/485, 20 mA) is being used. • Verify cable to indicator. • Verify that data is being transmitted to the XR from the indicator and that the data string contains numeric characters.
Display reads <i>Err 2</i> .	<ul style="list-style-type: none"> • Data String Auto-Learn has failed or Radio not receiving. • Verify the correct terminal (RS-232, 422/485, 20 mA) is being used. • Verify cable or radio connection to indicator. • Verify that a data string is being sent to the XR from the indicator and that the data string contains either an STX character (ASCII 02) or a CR character (ASCII 13).
Display reads <i>Err 3</i> .	<ul style="list-style-type: none"> • The XR is receiving data on multiple communications ports.
STATUS light NOT blinking (OFF)	<ul style="list-style-type: none"> • Verify that unit has power. When powered, if the Status light remains OFF, the processor is not running.
STATUS light blinking fast (3/second) for longer than 30 seconds:	<ul style="list-style-type: none"> • The XR is not able to Auto-Learn the data string or baud rate. See Error Messages <i>Err 1</i> and <i>Err 2</i>.
RS232 light not flashing	<ul style="list-style-type: none"> • Verify the RS232 terminal is being used and check communications wiring at the indicator. • Verify that data is being sent to the XR from the indicator and that the data string contains numeric characters.

RS485 light not flashing:	<ul style="list-style-type: none"> • Verify the RS485 terminal is being used and check communications wiring at the indicator. • Verify that data is being sent to the XR from the indicator and that the data string contains numeric characters.
20mA light not flashing:	<ul style="list-style-type: none"> • Verify the 20mA terminal is being used and check communications wiring at the indicator. • Verify that data is being sent to the XR from the indicator and that the data string contains numeric characters. • Make sure the correct mode (ACTIVE or PASSIVE) is selected on the controller board (SW10).
RADIO light not flashing:	<ul style="list-style-type: none"> • Check that the radio module is properly installed. Ensure that the internal antenna cable is connected to the radio module and the external antenna. • No data is being sent from the wireless transceiver connected to the scale indicator.

11 Parts

Part Number	Description
XR-8M ONLY:	
AWT20-504328	XR-8M DISPLAY BOARD, QTY 2 PER UNIT
XR-12M ONLY:	
AWT20-504329	XR-12M DISPLAY BOARD, QTY 2 PER UNIT
PARTS COMMON TO BOTH:	
AWT20-504327	XR-8M/12M CONTROLLER BOARD
AWT20-504391	XR-8M/12M ENCLOSURE
AWT20-504331	XR-8M/12M FRONT COVER
AWT20-504332	XR-8M/12M ELECTRONICS MTG PLATE
AWT20-504333	XR-8M/12M NON-GLARE LENS
60339-0022	BREATHE VENT
AWT25-500616	EXTERNAL KEYPAD W/ LIGHT SENSOR
60339-0048	POWER SUPPLY
60339-0055	11" RIBBON CA
60339-0063	21" RIBBON CA
60339-0071	9" GND WIRE
60339-0089	11" GND WIRE
60339-0097	POWER SUPPLY TO CONTROLLER BOARD CABLE ASSEMBLY
60339-0105	EXT. PWR CORD
OPTIONS FOR BOTH:	
AWT25-500617	TEMPERATURE OPTION
AWT05-503348	POLE BRACKET
60339-0113	INTEGRATED RF MODULE W/ANT.

Avery Weigh-Tronix



Avery Weigh-Tronix USA

1000 Armstrong Dr.

Fairmont MN 56031 USA

Tel:507-238-4461

Fax:507-238-4195

Email: usinfo@awtxglobal.com

www.wtxweb.com

Avery Weigh-Tronix UK

Foundry Lane,

Smethwick, West Midlands,

England B66 2LP

Tel:+44 (0) 8453 66 77 88

Fax: +44 (0)121 224 8183

Email: info@awtxglobal.com

www.averyweigh-tronix.com