



ZM3xx/4xx Controller Installation Guide


Below is a quick reference to show position and location of the various card layouts available to purchase. Use the #6-32 standoffs provided with the kits to install your card. The panduit mount tabs are shown in relation to the subsequent card. Field install panduits and ties as needed for your card/harness assembly.




ZM OPTO AWT15-501862




SSCU-8 AWT15-501863




GSE 16 IO AWT15-501864




RS-232 AWT15-501865



2X RS-232 AWT15-501871





DIN RAIL AWT15-501872





SIDE AND COVER PANDUITS

ZM3_4 Controller.cdr



ZM3_4 Controller.cdr



Avery Weigh-Tronix



Avery Weigh-Tronix USA

1000 Armstrong Dr.
Fairmont MN 56031 USA
Tel: 507-238-4461
Fax: 507-238-4195
Email: usainfo@awtx-itw.com
www.averyweigh-tronix.com

Avery Weigh-Tronix UK

Foundry Lane,
Smethwick, West Midlands,
England B66 2LP
Tel: +44 (0) 8453 66 77 88
Fax: +44 (0)121 224 8183
Email: info@awtxglobal.com
www.averyweigh-tronix.com