



ZM5xx/6xx Controller Installation Guide

Below is a quick reference to show position and location of the various card layouts available to purchase. Use the #6-32 standoffs provided with the kits to install your card. Mount the panduit tabs for the safest and most efficient routing.


Vertical wire duct (default configuration)




3X SSCU-8 CARDS




3X ZM OPTO CARDS




3X 16 I/O CARDS



6X EXPANSION CARDS




DIN




EMPTY


Horizontal wire duct (User configuration)




2X SSCU-8




2X ZM OPTO




2X 16 I/O CARD




4X EXPANSION (RS-232)



Z-SERIES



DIN RAIL



EMPTY

